

# Squier Deluxe Jazz Bass Active IV

030-0574-5xx



Part#	Description
0062408000	Tuners, Squier Deluxe Active Jazz Bass IV (set of 4)
0079901000	String Guide, Chrome, Squier Deluxe Active J Bass
0079902000	String Nut, Squier Deluxe Active Jazz Bass
0079903000	Electronic Backplate, Squier Deluxe Active J Basses
0074623000	Battery Case, Squier Deluxe Active J Basses
0079904000	Jack Assembly, Squier Deluxe Active J Basses
0079905000	Knobs, Squier Deluxe Active J Basses, (Set of 4)
0079906000	Electronics ASSY, SQ DLX Active J Basses (includes pots, toggle, PCB, and mounting hardware)
0079907000	Pickup, Neck, Squier Deluxe Active J Bass IV
0079908000	Pickup, Bridge, Squier Deluxe Active J Bass IV
0079909000	Bridge Assembly, Squier Deluxe Active J Bass IV
0079910000	Wrench Kit, Squier Deluxe Active J Basses (truss rod wrench and saddle adjust wrench)