




## Squier Std. Black & Chrome HSS Strat

**Rosewood- m/n 0321703506**

<u>Loc #</u>	<u>Description</u>	<u>Part Number</u>
1	Standard Tuners (set of 6)	005-5426-000
2	Bone Nut (blank) (2)	099-4920-000
3	Vintage String Guides (pack of 2)	099-4910-000
4	Strap Buttons (2)	099-4915-000
5	Pickguard (mirror)	006-9880-000
5a	Pickguard Screws (24)	099-4923-000
6	Standard Neck Pickup	005-5381-000
7	Standard Middle Pickup	005-5382-000
8	Standard Bridge Pickup	005-5384-000
9-11	500K Split Shaft Pot	006-2730-000
9-11a	Volume/Tone Knob Set (chrome)	005-1793-000
12	5 Way Pickup Selector Switch	005-5412-000
12a	Switch Tip (2) (black)	099-4939-000
13	Output Jack (2 pack)	004-7329-049
17	Jack Plate (chrome)	099-1940-100
18	Bridge Assembly	005-5408-000
18a	Tremolo Arm	004-1359-000

# Wiring Diagram



## Control Function

5 WAY SWITCH POSITION					
5	4	3	2	1	
<b>T1</b>	<b>T1&amp;T2</b>	<b>T2</b>	<b>T2</b>	<b>NT</b>	
					← NECK PICKUP (A)
					← MIDDLE PICKUP (B)
					← BRIDGE PICKUP (C)
					← BRIDGE PICKUP (D)
	PICKUP IS ON		INDICATES POSITION OF 5 WAY SWITCH		
	PICKUP IS OFF				
<b>A</b>	PICKUP (NECK)	<b>T1</b>	TONE 1		
<b>B</b>	PICKUP (MIDDLE)	<b>T2</b>	TONE 2		
<b>C &amp; D</b>	PICKUP (BRIDGE)	<b>NT</b>	NO TONE		

